

HEADSUP

STREAMING VIDEO RECORDER

Model: WC1



USER MANUAL



What's included?



Also Included



Adaptor



USB Cable

First things first

Fully charge HeadsUp before using. Plug the USB charging cable into the USB charge port on HeadsUp located at bottom of unit and attach the other end to the AC adapter then plug into AC outlet.

You may also plug the cable into a charging USB port such as a PC or portable power pack. Red charging indicator light will blink while HeadsUp is charging. HeadsUp should fully charge in 2 hours.

Normal charge will last 3 hours while recording with Wi-Fi off and 2 hours with Wi-Fi on.


Getting to know HeadsUp

Power On - Press Power over 2 sec, Green LED will show when power is on.

Power Off - Push Power over 2 sec again to Power off. HeadsUp will auto Power off if no functions occur over one minute.

Record Video - You can control recording from App or direct from HeadsUp. Audio confirmations will guide your selections. With the power on, press Record to Record Video. Green LED blinks while recording, Push Record again to Stop Recording.

Capture Image - Press PH to capture image.



Get a data card

Acquire a micro TF data card (not Included). The card must be high speed read write with a rating between 6C to 10C and a max Storage of 64 GB. Insert card into card slot on bottom of HeadsUp.

Note: Be sure card is in the direction of the image at the port.

We recommend cards with flexible adapters as shown here.



Get the app

Frame your phone's camera around the scan code below to be directed to the App in your corresponding App Store or go to your App Store and search HeadsUp Camera.



HEADSUP CAMERA




Frame phone camera around scan code here. Select HeadsUp Camera App when it appears on your phone screen.



Open the app

Introduction Screen 1

- Outlines button functions on HeadsUp.
- Power On then tap "Next"



Introduction Screen 2


Videos play from an avi player. Most phones have one pre-loaded. In the event your phone won't play the video, download an avi player from your app store.

Then tap Next



App Home Screen

- User Manual can be accessed by clicking the User Manual icon.
- Media files that you have downloaded to your phone are referenced in the Download file here. Click Download Folder Icon to review. Note: These files can be shared to social media only from phone photos app or Gallery.
- Connect Bluetooth and Wi-Fi to phone. See Wi-Fi Connect and Bluetooth Connect for detailed instructions.
- After Wi-Fi connection is made, tap "Next" on this screen. This will bring you to the Control Screen.



Note:

Introduction screens 1 and 2 will not reappear after initial opening of App. App Home Screen will appear first from this point forward whenever opening app. .

Let's get connected


HeadsUp utilizes Wi-Fi Direct® to set up its own private network. There is no need for Internet or Cellular phone service to record and stream to your phone.

There are two connections to make with your phone, Wi-Fi & Bluetooth. Bluetooth connection is not required for recording and streaming but is required for the convenience of taking calls or listening to music on HeadsUp.

Wi-Fi Connect

Turn Wi-Fi on - With Power On, press and hold Wi-Fi button for 2 seconds to turn on, then turn phone Wi-Fi on. The yellow LED on HeadsUp will blink for one minute or will turn off when HeadsUp is connected to a phone. Connect to Wi-Fi then enter password, abc12345. Note: Wi-Fi password cannot be changed.

Note: To avoid confusion with other HeadsUp users, you can change your SSID / device name. With Wi-Fi connected; from app, go to Settings/Wi-Fi name, then select and change. Name must be a minimum of 3 characters, letters & numbers only.




Bluetooth Connect

HeadsUp has Bluetooth. You can use it to take phone calls and to assist with making videos and images when choosing not to use the phone.

- Turn phone and HeadsUp Bluetooth On. Blue LED light will start blinking on HeadsUp.
- On Phone Bluetooth screen, select WC1 when it appears.
- Press Bluetooth button to answer incoming calls on HeadsUp.
- If you wish to pause Bluetooth audio, such as when playing music from phone, Press Bluetooth button.
- Use Phone volume control to adjust the sound.
- Press the Bluetooth button on HeadsUp to turn Bluetooth Off.

Note:

Skip Bluetooth connection if do not wish to receive phone calls or listen to music on HeadsUp to avoid unnecessary use of battery.



Making & Streaming Videos

Access Control Screen by selecting “Next” Button from Home Screen.

Step 1

On Control Screen, select mode icon (#6 in image below) and select “Record”.

Step 2

You can adjust the following:

Resolution - Open Resolution setting and make your selection. Note: the higher the resolution the more space will be used on your data card.

Loop – Select "Off " or auto recording loop times. Tap "Done".



WDR – Wide Dynamic Range can balance difficult lighting situations. Select "On" or "Off".

Step 3 – Control Screen

Take the Video using phone from Control Screen - Put HeadsUp on your head or neck. Make sure it's on and is connected to app via private Wi-Fi. From Control Screen Press Start Record button. Your video will live stream to your phone and will auto save to your data card. You can stream recorded files to your phone as well while connected.

Take Video without phone – HeadsUP can take the video without using the phone. HeadsUp will provide voice confirmations to assist you in selecting the correct button. Recorded video can be streamed to phone for viewing in the App.

1. FileManager
2. Settings
3. Live Display
4. Home
5. Start / Stop Record
6. Mode – Video / Image



Taking & Streaming Pictures

Step 1

Open Control Screen, select mode Icon and select Capture Image.

Step 2

You can adjust the following:

Resolution – Open Resolution setting and Make your selection.
Note: the higher the resolution The more space it will take up on Your data card.

Exposure – Open and scroll to desired exposure.

Quality – Select desired Quality
Sharpness – Select desired setting.
ISO – Select desired setting.



Anti-Shaking – Turn On or Off.

White Balance – Select based on lighting condition.

Step 3

Take the Image - Put HeadsUp on your head or neck, Make sure it's on and fully connected, then frame your shot and press Start button. Your image will autosave to your data card.

Take Image without phone – HeadsUp can take the image without using the phone. Image can be streamed from app for viewing.



Managing Data

Video and image files appear in the File Manager. From the Control Screen, open File Manager to access.

Fileformats

- Video files are .avi format.
- Image files are .jpg format.

Manage from phone

Tap desired file for menu options.

Play – Select to play on phone. Note: You will need to download first to hear the audio.

Download – Select download for full AV play and for simple posting to Social Media.

Note: When uploading to external locations such as Social Media, first disconnect HeadsUp's private Wi-Fi network from your phone and connect phone to normal Wi-Fi network.

Caution: If you upload or send files via cellular signal you may incur data charges depending on your cellular data program.

Info – Select to view title, date taken, time of video and file size.

Delete – Select to delete, then confirm deletion.


Manage from PC

Option 1:

1. Connect HeadsUp to PC using the USB data / charge cable.
2. Drag and drop from the HeadsUp file to desired file on PC.

Option 2:

1. Remove the data card from HeadsUp.
2. Use USB or full data card adapters with data card to input into PC



Need help?

- If HeadsUp fails to display Camera live view, Tap Disconnect Wi-Fi, tap Wi-Fi Icon to reconnect again or just press Reset button and start over.
- To save Battery Power, turn Wi-Fi off. Press Wi-Fi Button over 2 sec. to turn it off, then record the without Wi-Fi. Note: Live View will not be available with Wi-Fi off.
- Phones without an avi player installed will not show the thumbnail (file image) of a video file. You can easily obtain and install an avi player from your App Store.
- If HeadsUp won't operate. First check battery charge. If battery charge is okay, long press the reset button for 5 seconds.
- There will be no audio if you play the videos without downloading, Download the recorded videos before playing for full AV playback.
- If record function does not begin, check the data card. The card must be high speed read write with rating between 6C to 10C with a maximum storage of 64 GB.
- If time & date stamp is incorrect in your recorded files, please Wi-Fi connect HeadsUp to your phone. Time & date will now be sync and be aligned.

Note: Data card is not included with purchase.

Call us for Assistance

Toll Free / 9AM - 7PM EST daily except holidays

888-808-BEAN

E-mail us for Assistance

support@beantech.net

Safety & Care

Safety Precautions

Following these precautions reduces the risk of and damage to the product.

PROTECT THIS DEVICE: Keep device dry and out of sunlight when not using.

SWITCH OFF IN RESTRICTED AREAS: Do not use where mobile devices are not authorized or when it may cause interference or danger. Do not operate while driving.

MEDICAL IMPLANTS: This device emits Radio Frequency energy and may interfere with medical devices. Consult a doctor or the manufacturer of the medical equipment to see if the equipment is adequately protected from Radio Frequency energy.

AUTHORIZED PERSONNEL: Only qualified personnel are authorized to repair this product. Do not open this product other than to change the batteries. There are no user-serviceable parts inside.

ACCESSORIES: Only use Charger which is provided with Product. Do not use any other Charger.

DISPOSAL OF YOUR DEVICE: This product should not be disposed of with other household waste. To prevent possible harm to the environment or human health, recycle it responsibly.

Compliance with FCC Regulations

ATTENTION: This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Warranty

This device comes with a one-year warranty. Please visit our website for full details. www.beantech.net, under HeadsUp.



www.beantech.net